


# autarco

Installation and Operation Manual

---

Solar Inverters MX Mark II series



## Contact Information

Autarco Group B.V.  
Schansoord 60  
5469 DT Erp  
The Netherlands

[www.autarco.com](http://www.autarco.com)  
[info@autarco.com](mailto:info@autarco.com)

## Other Information

This manual is an integral part of the unit. Please read the manual carefully before installation, operation or maintenance. Keep this manual for future reference.

Product information is subject to change without notice. All trademarks are recognized as the property of their respective owners.

© Autarco Group B.V.  
All rights reserved.

## Table of Contents

<b>1.</b>	<b>Introduction</b>	<b>4</b>
1.1	Read this first	4
1.2	Target Audience	4
1.3	Product versions covered by this document	5
<b>2.</b>	<b>Preparation</b>	<b>2</b>
2.1	Safety instructions	2
2.2	Package contents	3
2.3	Internal DC switch	3
2.4	Explanations of symbols on inverter	3
<b>3.</b>	<b>Product information</b>	<b>4</b>
3.1	Overview	4
3.2	Product identification	4
3.3	Product overview	5
<b>4.</b>	<b>Installation</b>	<b>6</b>
4.1	Safety	6
4.2	Mounting instructions	6
4.3	Safety clearance	7
4.4	Mounting procedure	8
<b>5.</b>	<b>Electrical installation</b>	<b>9</b>
5.1	AC connection	9
5.2	DC connections	12
5.3	Inverter commissioning sequence	13
<b>6.</b>	<b>Operation</b>	<b>13</b>
6.1	LED indicator lights	13
6.2	Inverter display	13
6.3	Information	14
6.4	Settings	15
6.5	Advanced info	15
6.6	Advanced Settings	16
6.7	Temperature derating	18
<b>7.</b>	<b>Monitoring setup and system registration</b>	<b>19</b>
<b>8.</b>	<b>Maintenance</b>	<b>19</b>
<b>9.</b>	<b>Disposal</b>	<b>19</b>
<b>10.</b>	<b>Troubleshooting</b>	<b>20</b>
10.1	General	20
10.2	Internal component fault	20
10.3	Grid errors	21
10.4	System and design fault	22
<b>11.</b>	<b>Product specifications</b>	<b>23</b>

## 1. Introduction

### 1.1 Read this first

This manual contains important information for use during installation and maintenance of the MX-MII series Autarco inverter.

To reduce the risk of electrical shock, and to ensure the safe installation and operation of the MX-MII series Autarco inverters, the following safety symbols appear throughout this document to indicate dangerous conditions and important safety instructions.



**WARNING!** Indicates safety instruction, which if not correctly followed, can result in injury or property damages.



**RISK OF ELECTRIC SHOCK!** Indicates safety instructions, which if not correctly followed, could result in electric shock.



**HOT SURFACE!** Indicates safety instructions, which if not correctly followed, could result in burns.

### 1.2 Target Audience

This manual is intended for anyone who uses Autarco MX-MII series inverter. Before any further action, the operators must first read all safety regulations and be aware of the potential danger to operate high-voltage devices. Operators must also have a complete understanding of this device's features and functions.



**ATTENTION!** Qualified personnel means a person with valid license from the local authority in:

- Installing electrical equipment and PV power systems (up to 1000 V).
- Applying all applicable installation codes and using Personal Protective Equipment.
- Analyzing and reducing the hazards involved in performing electrical work.



**WARNING!** Do not use this product unless it has been successfully installed by qualified personnel in accordance with the instructions in chapter 4 "Installation".

## 1.3 Product versions covered by this document

The main purpose of this user manual is to provide instructions and detailed procedures for installing, operating, maintaining, and troubleshooting the MX-MII series of Autarco inverters which includes the following models:

- S2.MX3000(S)-MII
- S2.MX3600(S)-MII
- S2.MX4000(S)-MII
- S2.MX4600(S)-MII
- S2.MX5000(S)-MII

The “S2.” In the product code means the product is a grid-tied inverter. If the product has an “S” at the end it comes with integrated DC switches.

The item code or SKU will include an additional number at the end. The final number references the default grid standard and colour of inverter. For example, S2.MX3000S-MII.1 is the 3kW model with Dutch grid standard as default, integrated DC switch and Autarco blue cover.

Please keep this user manual available at all times in case of emergency.

## 2. Preparation

### 2.1 Safety instructions



DANGER! Do not touch any internal components whilst the inverter is in operation.



DANGER! Do not stand close to the inverter during severe weather conditions such as lightning, etc.



Make sure you completely cover the surface of all PV arrays with opaque (dark) material before wiring them or make sure the DC circuit breaker or equivalent DC isolator is disconnected. This is because photovoltaic (PV) arrays create electrical energy when exposed to light, and could cause a hazardous condition.



The MX-MII series inverter must only be operated with PV arrays of protection class II, in accordance with IEC 61730, class A.



WARNING! The PV inverter will become hot during operation; please don't touch the heat sink or peripheral surface during or shortly after operation.




NOTICE! Do not directly connect AC output of the inverter to any private AC equipment. The PV inverter is designed to feed AC power directly into the public utility power grid.




WARNING! The installation, service, recycling and disposal of the inverters must be performed by qualified personnel in compliance with national and local standards and regulations. Please contact your dealer to get the information of authorized repair facility for any maintenance or repairmen.

Any unauthorized actions including modification of product functionality of any form will affect the validation of warranty service; Autarco may deny the obligation of warranty service accordingly.

## 2.2 Package contents




Autarco MX-MII series inverter




AC plug



Mounting bracket + locking screws



MC4 connector pairs  
S4.MC4F/MC4M



Instruction manual

## 2.3 Internal DC switch

Please verify whether your Autarco MX-MII series inverter is equipped with an internal DC switch. This switch can be found on the bottom of the inverter (see 3.3). If there isn't an internal DC switch it is important to apply an external DC disconnecter in order to completely disconnect the solar PV module strings from the inverter.

## 2.4 Explanations of symbols on inverter

<p>10 min.</p>	<p><b>DANGER - HIGH ELECTRIC VOLTAGE</b> This device is directly connector to public grid. All work to the inverter shall be carried out by qualified personnel only. There might be residual currents in inverter for up to 10 minutes because of large capacitors.</p>
	<p><b>ATTENTION</b> This device directly connected to electricity DC generators and the public AC grid.</p>
	<p><b>DANGER – HOT SURFACES</b> The components inside the inverter will get hot during operation, DO NOT touch aluminum housing during operating.</p>
	<p><b>ATTENTION</b> In case of any work to the inverter, always refer to this manual for detailed product information.</p>
	<p><b>ATTENTION</b> This device SHALL NOT be disposed of in residential waste. Please go to Chapter 9 “Recycling and Disposal” for proper treatments.</p>
	<p><b>CE MARK</b> This equipment conforms to the basic requirements of the EU guideline governing low voltage and electromagnetic compatibility.</p>

## 3. Product information

### 3.1 Overview

Autarco MX-MII series grid tied inverters are state of the art, high efficiency, robust and reliable grid tied inverters at the best price quality ratio available. They are easy to install and carry a standard 5 year product warranty which is extendable to 15 years. Our rigorous quality control and testing facilities guarantee Autarco inverters meet the highest quality standards possible. These inverters are the key to our international track record of delivering extremely reliable solar power solutions.

Key features:

- Maximum efficiency of 98.1%
- Wide MPPT voltage range
- Low turn off voltage
- High enclosure protection class IP65
- Silent design using convection cooling principle
- Standard 5 year product warranty, extendable to 15 years
- Compatible with WiFi, GPRS, 3G, Smart Home and LAN-cable
- Optional integrated DC switch



For full specifications please see chapter 11 “Product specifications”.

### 3.2 Product identification


You can identify the inverter by the serial number (S/N) sticker on the side of the inverter. Important electrical specification can also be found on the label which can be found on the right side of the inverter housing. Do not remove the label or the serial number as this voids the product warranty.



### 3.3 Product overview



- A: Inverter cover
- B: LED light – POWER
- C: LED light – OPERATION
- D: LED light – ALARM
- E: LCD display 2x16 characters
- F: Escape key
- G: Up key
- H: Down key
- I: Enter key
- J: Current Clamp port
- K: DC inputs
- L: DC switch (optional)
- M: Communication port
- N: Demand Response Port
- O: AC output



## 4. Installation

### 4.1 Safety



**DANGER!** Do not install the inverter near flammable or explosive items.




**WARNING!** The installation must be performed by qualified personnel and in compliance with national and local standards and regulations.  
This inverter will be connected to a high voltage DC power generator and AC grid. Inappropriate installation may also jeopardize the life span of the inverter.



The installation site must have good ventilation conditions. Direct exposure to intense sunshine is not recommended.

### 4.2 Mounting instructions

- The inverter is suitable for outdoor and indoor installation.
- Vertical installation is recommended, with a maximum inclination of 15° backwards.
- Make sure the mounting wall is strong enough to hold the weight of the inverter.
- The ambient temperature of installation site should be between -20 °C and +60 °C.
- It is not recommended that the inverter is exposed to the direct sunshine.
- Make sure of ample ventilation at installation site, insufficient ventilation may reduce the performance of the electronic components inside the inverter and shorten the life span of the inverter.




### 4.3 Safety clearance




Caution! Make sure heat sinks are out of reach of children.


Observe the following minimum clearances to walls:



## 4.4 Mounting procedure

- Step 1** — Mount the wall bracket onto the mounting wall with appropriate screws/plugs
- Step 2** — Lower the inverter onto the bracket, and secure with the locking screws.





## 5. Electrical installation



**DANGER!** This inverter will be connected to a high voltage DC power generator and AC grid. The installation must be performed by qualified personnel and in compliance with national and local standards and regulations

### 5.1 AC connection



**DANGER!** Never connect or disconnect the connectors under load.



**NOTICE!** The AC connection to the electrical distribution grid must be performed only after receiving authorization from the utility that operates the grid.




**NOTICE!** Make sure to set the correct grid standard as part of system commissioning, see chapter 6.6.

The Autarco inverter is equipped with an integrated Residual Current Protective Device (RCPD) and Residual Current Operated Monitor (RCOM). The RCOM will detect the volume of the leakage current and compare it with the expected value, if the leakage current exceeds the permitted range, the RCPD will disconnect the inverter from the AC load.


If regulations in the country of installation stipulate an external Residual Current Device (RCD), you must use a device with a tripping threshold of 100 mA or more. For the MX-series we recommend to use at least 100 mA. A type “A” RCD can be used in accordance with our “Manufacturer’s declaration for usage of residual current devices”. Contact Autarco for advice.

The AC cable used must be dimensioned in accordance with any local and national directives on cable dimensions which specify requirements for the minimum conductor cross-section. Cable dimensioning factors are e.g.: nominal AC current, type of cable, type of routing, cable bundling, ambient temperature and maximum specified line losses.


We recommend 4mm 105 °C cable with resistance lower than 1.5 ohm.




**Step 1 —** Slide the cable gland cap, cable gland body and adapter to the cable.




**Step 2 —** Strip outer jacket 60mm and strip each cable insulation about 12±1mm.



**Step 3 —** Insert cable strands into connector socket, and lock the screws. Make sure to fit the ground wire into the PE hole.



**Step 4 —** Fit the adapter, cable gland body and cable glad cap to the connector as per below.



**NOTICE!** It is important that the AC wires are connected to the right terminals as indicated by the “L”, “N” and “Earthing” symbols on each AC connector. In some countries a second protective conductor is required as a matter of principle. In each case, observe the applicable regulations for the site.



The AC connection to the electrical distribution grid must be performed only after receiving authorization from the utility that operates the grid.

Always use separate fuses for consumer load. Use dedicated circuit breakers with load switch functionality for load switching.

The selection of the mains circuit breaker rating depends on the wiring design (wire cross- section area), cable type, wiring method, ambient temperature, inverter current rating etc. Derating of the circuit breaker rating may be necessary due to self-heating or if exposed to heat.

	<b>S2.MX3000(S)</b> <b>-MII</b>	<b>S2.MX3600(S)</b> <b>-MII</b>	<b>S2.MX4000(S)</b> <b>-MII</b>	<b>S2.MX4600(S)</b> <b>-MII</b>	<b>S2.MX5000(S)</b> <b>-MII</b>
Max. AC current (A)	15.7	16.0	21.0	23.8	25.0
Recommended fuse type gL/gG or comparable automatic circuit breaker rating (A)	20	20	25	35	35



**DANGER!** No consumer load should be applied between the mains circuit breaker and the inverter.



## 5.2 DC connections

Please always use the MC4 connectors from the inverter box to connect strings to the inverter.



**DANGER!** Never connect or disconnect the connectors under load.

MX-MII series inverters have two MPP trackers. The DC characteristics of each model is shown in the table below:

Inverter	MPP tracker	Max DC power	Max DC voltage	Max. DC current per MPPT
S2.MX3000(S)-MII	2	3500W	600V	11A
S2.MX3600(S)-MII		4200W		
S2.MX4000(S)-MII		4600W		
S2.MX4600(S)-MII		5300W		
S2.MX5000(S)-MII		5800W		



**DANGER!** Do not connect the strings with an open circuit voltage greater than the Max DC voltage of the inverter.

To connect the PV generator to the inverters we use 4mm<sup>2</sup> or 6mm<sup>2</sup> PV cable and MC4 connectors. For details on how to assemble MC4 connector please refer our MC4 connector manual.



**DANGER!** For protection against electric shock, MC4 connectors must be isolated from the PV array while being assembled or disassembled.



DC connections must not be unplugged while under load. They can be placed in a no-load state by switching off the DC/AC converter or breaking the DC circuit interrupter. Plugging and unplugging while under voltage is permitted.



**CAUTION!** MC4 connectors are watertight IP67 but cannot be used permanently under water. Do not lay the MC4 connectors on the roof surface.



If any tools or parts are used in the MC4 connector assembly other than those listed in the MC4 connector manual, neither safety nor compliance with the technical data can be guaranteed.

## 5.3 Inverter commissioning sequence

Turn ON	Turn OFF
1. Connect AC side (if not connected yet)	1. Switch OFF the AC switch
2. Connect DC side (if not connected yet)	2. Switch OFF the DC switch
3. Switch ON the DC switch	
4. Switch ON the AC switch	

## 6. Operation

### 6.1 LED indicator lights

There are three LED status indicator lights in the front panel of MX-MII series inverters. The left POWER light (red) indicates power status of the inverter. The middle OPERATION light (green) indicates the operation status. The right ALARM light (yellow) indicates the alarm status. Table 3.1 explains their meanings.

Light	Status	Description
● POWER (red)	ON	The PV array provides power to the inverter
	OFF	The PV array does not provide power to the inverter
● OPERATION (green)	ON	The inverter is feeding AC power to the grid
	OFF	The inverter is not feeding AC power to the grid
	FLASHING	The inverter is initializing
● ALARM (yellow)	ON	There is a fault. Refer to the inverter display and chapter 10 of this manual for details
	OFF	The inverter is operation normally

When inverter DC switch and AC switch have been turned on the inverter will start initializing. After approx. 3 minutes the inverter will start normal operation with the inverter display showing GENERATING.

### 6.2 Inverter display



**NOTICE!** During normal operation, make sure the optional integrated DC switch is switched “on”.

The display content consists of 2 lines. During regular operation the display shows the current power and operation status alternatively for 10 seconds. Pressing the UP or DOWN buttons will manually cycle through these two displays. Pressing the ENTER button gives access to the main menu which has four sub menus:

- Information, described in detail in chapter 6.3.
- Settings, described in detail in chapter 6.4.
- Advanced information, described in detail in chapter 6.5.
- Advanced settings, described in details in chapter 6.6.

By pressing UP or DOWN keys you can cycle through these sub menus and click ENTER to go into the submenu.

## 6.3 Information

The MX-MII series inverters main menu provides access to operational data and information. The information is displayed by selecting "Information" from the main menu. By default the inverter display will scroll through the information states below. Pressing the ENTER key will lock or unlock the current display. You can also press UP or DOWN keys to manually scroll through. By pressing the ESC key returns to the main menu.

State	Description
V_DC1 %VALUE% I_DC1 %VALUE% A	Shows the input voltage (V) of the MPPT1 Shows the input current (A) of the MPPT1
V_DC2 %VALUE% I_DC2 %VALUE% A	Shows the input voltage (V) of the MPPT2 Shows the input current (A) of the MPPT2
V_AC %VALUE% I_AC %VALUE% A	Shows the voltage (V) of the grid Shows the current (A) of the grid
Status: %VALUE% Power: %VALUE% W	Shows the status of the inverter Shows current output power (W) of the inverter  For any status other than "Generating" and "Initializing" please refer to chapter 10 for troubleshooting
Grid frequency F_Grid %VALUE% Hz	Shows current frequency (Hz) of the grid
Total Energy %VALUE% kWh	Shows total energy output (kWh)
This Month: %VALUE% kWh Last Month: %VALUE% kWh	Total energy output in this month (kWh) Total energy output of last month (kWh)
This day: %VALUE% kWh Last day: %VALUE% kWh	Total energy output in this day (kWh) Total energy output of yesterday (kWh)
Inverter SN %VALUE%	Shows serial number of the inverter
P_EPM: %VALUE% W I_EPM: %VALUE% A	Shows power of EPM Shows current of EPM
Work Mode: %VALUE% DRM Number: %VALUE%	Shows work mode of the inverter Shows DRM number
Meter EnergyP %VALUE% kWh	Shows The active power

## 6.4 Settings

The following options are available under the Settings submenu:

Set Time and Date	Press UP/DOWN keys to set change element Press ENTER key to move to next element Press ESC key to save date and return
Set Address	Assign a number (##) to the inverter to distinguish between multiple inverters on a single Wi-Fi device. Not necessary for installations of single inverters.  Press UP/DOWN keys to set change number Press ENTER key to save the setting Press ESC key to return
Restore Settings	Delete alarm messages that have been generated



**WARNING!** Access to this section of the menu is for Autarco qualified and accredited technicians only. Unauthorized access will void the product and system warranty.

Screen can be scrolled through with UP/DOWN keys to see the information as per the table below. Press ENTER key to enter a submenu. Press ESC key to go back to the main menu.




Alarm Messages	Scroll through the last ten alarm messages for trouble shooting purposes. Press UP/DOWN keys to cycle through alarm messages Press ESC key to return
Running Messages	The screen shows the temperature of the inverter in degrees Celcius, and current grid standard, etc...
Version	The screen shows the operating software version of the inverter
Daily Energy	Shows energy generation for a selected day
Monthly Energy and Yearly Energy	Shows energy generation for a selected month and year
Daily Record	Shows history of setting changes. ONLY for maintenance person.
Communication data	The screen shows information interpretable to qualified technicians only
Warning Message	Shows latest 100 warning messages.

## 6.5 Advanced Settings




WARNING! Access to this section of the menu is for Autarco qualified and accredited technicians only. Unauthorized access will void the product and system warranty.

Screen can be scrolled through with UP/DOWN keys to see the information as per the table below. Press ENTER key to enter a submenu. Press ESC key to go back to the main menu.

<p>Select grid standard</p>	<div style="text-align: center;">  <p>WARNING! Set GRID OFF (see below) before changing this setting.</p> </div> <p>Press UP/DOWN keys to cycle through available standards</p> <ul style="list-style-type: none"> <li>• AS4777</li> <li>• VDE0126</li> <li>• UL1741</li> <li>• G83</li> <li>• User defined</li> </ul> <p>Press ENTER key to save the setting Press ESC key to cancel and return</p> <p>When selecting User defined the following upper and lower values have to be set for voltage and frequency:            OV-V: 240-270V            UV-V: 180-210V            OV-G-F: 50.3-52.0Hz (60.3-62.0Hz)            UV-G-F: 47.0-49.5Hz (57.0-59.5Hz)</p> <p>Press UP/DOWN keys to scroll through these values            Presss ENTER key to edit the selected value            Press UP/DOWN keys to change the selected value            Presss ENTER key to save and return            Press ESC key to cancel and return</p> <div style="text-align: center;">  <p>WARNING! Set GRID ON (see below) before new standard is activated.</p> </div> <div style="text-align: center;">  <p>WARNING! Please note that the User-Def standard is not to be used without the agreement of the local grid authority.</p> </div>
<p>Grid ON/OFF</p>	<p>Press UP/DOWN keys to cycle through grid ON/OFF options            Press ENTER key to save            Press ESC key to return</p>
<p>Clear Energy</p>	<p>Reset the inverters total kWh output to zero.</p>

New Password	Change the password to enter Advanced Info and Advanced Settings.
Power Control	This function use to set, <ol style="list-style-type: none"> <li>1. Output power</li> <li>2. Reactive power</li> <li>3. Out_P with restore</li> <li>4. Reactive_P with restore</li> <li>5. Select PF Curve</li> </ol>
Calibrate Energy	Press DOWN key to move the cursor, press UP key to revise the value Press ENTER key to save Press ESC key to return
Special settings	ONLY for maintenance person.
STD Model settings	ONLY for using in Australia
Restore Settings	Press ENTER key to restore Press ESC key to return
HMI Updater	ONLY for maintenance person
EPM Setting	Power export limitation settings should only be used when necessary.  <ol style="list-style-type: none"> <li>1.Set back flow power              Press UP/DOWN keys to set data, press ENTER key to set back flow power              Then Press DOWN key to move the cursor, Press UP key to change the number, Press ESC key to save and return.</li> <li>2.CT Sampling Ratio              Press UP/DOWN keys to set data, press ENTER key to set CT Parameter              Press ESC key to save and return.</li> <li>3.EPM ON/OFF              Press UP/DOWN keys to cycle through ON/OFF options              Press ENTER key to save, Press ESC key to return</li> <li>4.Fail Safe ON/OFF              Press UP/DOWN keys to cycle through ON/OFF options              Press ENTER key to save, Press ESC key to return</li> </ol> <p>CT Link Test              Before proceeding CT link test, please make sure:              - Load Power is not less than 500W              - Inverter is set to Grid OFF              - CT is correctly connected              - EPM is set to ON              Press ENTER key to show CT link test result, Press ESC key to return</p>
Restart HMI	ONLY for maintenance personnel
Debug Parameter	ONLY for maintenance personnel
DSP Updator	ONLY for maintenance personnel
Power Parameter	ONLY for maintenance personnel

The output power of the inverter varies with ambient temperature, as shown in the figure below.





## 7. Monitoring setup and system registration

The instructions about Wi-Fi setup and system registration can be found in separate manuals enclosed in the documentation that came with this Autarco system. For more information manual please contact your Autarco installer or refer to our website [www.autarco.com](http://www.autarco.com).

## 8. Maintenance

The MX-MII series inverters do not require regular maintenance. However, impurities such as dust and dirt accumulation on the heat sink may negatively affect the inverter's ability to dissipate heat. Any dirt or dust can be removed with a cloth or soft brush.



CAUTION! Do not touch the heat sink when the inverter is in operation. Turn OFF the inverter (see section 5.3) and allow for cooling down before cleaning.



CAUTION! Never use any solvents, abrasives or corrosive materials to clean the inverter.

## 9. Disposal

To comply with European Directive 2002/96/EC on waste Electrical and Electronic Equipment and its implementation as national law, electrical equipment that has reached the end of its life must be collected separately and returned to an approved recycling facility. Ignoring this EU Directive may have severe effects on the environment and your health.

## 10. Troubleshooting

### 10.1 General

Display message	Action
Blank screen	<ul style="list-style-type: none"> <li>• Check that all switches are in the ON position (including internal DC switch if present)</li> <li>• Check AC and DC power supply. If DC power is greater than 10W and string voltage greater than 100V the inverter should start.</li> <li>• If switches are on and AC and DC power supplies is available please contact installer.</li> </ul>

### 10.2 Internal component fault

Error type	Display message	Error code	Error description	Action
Over BUS DC voltage	OV-BUS	1021	Internal fault	<ol style="list-style-type: none"> <li>1. Restart inverter (up to three times).</li> <li>2. If error persists contact installer for replacement inverter.</li> </ol>
Under BUS DC voltage	UN_BUS	1012	Internal fault	
BUS pressure fault	UNB2_BUS	1024	Internal fault	
System initial fault	INI-PRO	1031	Internal fault	
Relay fault	Relay_PRO	1035	Internal fault	
DSP_B fault	DSP_B_PRO	1036	Internal fault	
DC injection	DCInj_PRO	1037	Internal fault	
12V under voltage fault	12Power_PRO	1038	Internal fault	

**a.**

Error type	Display message	Error code	Error description	Action
Over voltage	OV-G-V	1010	Grid voltage exceeds the standard set in the inverter	<ol style="list-style-type: none"> <li>1. Wait to see if the grid voltage returns within limits.</li> <li>2. If problem persists, check whether the grid standard is set correctly. Settings (see 6.6).</li> <li>3. Check V<sub>AC</sub>, grid voltage, in Information display of inverter (see 6.3). independent measurement of grid voltage to confirm that the inverter is correct. If the measured voltage is outside the local grid standard contact your local utility as it may require monitoring and adjustment.</li> <li>4. With agreement from utility it is possible to set a user defined voltage (see 6.6).</li> </ol>
Under voltage	UN-G-V	1011	Grid voltage is below the standard set in the inverter	
Over frequency	OV-G-F	1012	Grid frequency exceeds the standard set in the inverter.	<ol style="list-style-type: none"> <li>1. Wait to see if the grid frequency returns within limits.</li> <li>2. If a problem persists, check whether the grid standard is set correctly. Settings (see 6.6).</li> <li>3. Check grid frequency, in Information display of inverter (see 6.3). independent measurement of grid frequency to confirm that the inverter is correct. If the measured frequency is outside the local grid standard contact your local utility as it may require monitoring and adjustment.</li> <li>4. With agreement from utility it is possible to set a user defined frequency (see 6.6).</li> </ol>
Under frequency	UN-G-V	1013	Grid frequency is below the standard set in the inverter.	
Grid impedance	G-IMP	1014	High grid impedance	<ol style="list-style-type: none"> <li>1. Wait to see if the grid returns within limits.</li> <li>2. If problem persists please contact your local utility as it may require adjustment.</li> </ol>
No Grid	NO Grid	1015	The inverter cannot detect a grid.	<ol style="list-style-type: none"> <li>1. Check your AC power connections and switches.</li> <li>2. Restart the inverter.</li> <li>3. Call your local grid to resolve the black out.</li> </ol>

### 10.3 Grid errors

## 10.4 System and design fault

Error type	Display message	Error code	Error description	Action
Over DC voltage	OV-DC	1020	The DC input of the solar strings exceeds the inverters limits.	<ol style="list-style-type: none"> <li>1. Restart inverter (up to three times).</li> <li>2. Contact installer to:               <ol style="list-style-type: none"> <li>a. Perform independent measurement of string voltage to inverter reading is correct.</li> </ol> </li> <li>3. Rewire strings so that string voltage is within accepted range.</li> </ol>
Over temperature	TEM-PRO	1032	The internal temperature of inverter exceeds limits.	<ol style="list-style-type: none"> <li>1. Check location of inverter. Ensure it has adequate ventilation to direct sunlight.</li> <li>2. Contact installer to replace inverter in case problem persists.</li> </ol>
Short circuit fault	SHORT-PRO	1030	A short circuit has been detected in the system.	<ol style="list-style-type: none"> <li>2. Restart inverter (up to three times).</li> <li>3. Call installer to:               <ol style="list-style-type: none"> <li>a. Check for pinched, crimped or otherwise damaged cables.</li> <li>b. Check all switches for short circuit.</li> </ol> </li> <li>4. If error persists contact Autarco for replacement inverter.</li> </ol>
Ground fault	GROUND-PRO	1033	Current flow detected through ground conductor.	<ol style="list-style-type: none"> <li>1. Restart inverter (up to three times).</li> <li>2. Call installer to:               <ol style="list-style-type: none"> <li>a. Check if there is any current on the ground conductor.</li> <li>b. Check for pinched, crimped or otherwise damaged cables.</li> </ol> </li> <li>3. If error persists contact Autarco for replacement inverter.</li> </ol>
Current leakage	ILeak_PRO	1034	A current leak has been detected.	<ol style="list-style-type: none"> <li>1. Restart inverter (up to three times).</li> <li>2. Call installer to:               <ol style="list-style-type: none"> <li>a. Check if there is any current on the ground conductor.</li> <li>b. Check for pinched, crimped or otherwise damaged cables.</li> </ol> </li> <li>3. If error persists contact Autarco for replacement inverter.</li> </ol>

## 11. Product specifications

	S2.MX3000(S)- MII	S2.MX3600(S)-M II	S2.MX4000(S) -MII	S2.MX4600(S)- MII	S2.MX5000(S)- MII
<b>Input</b>					
Max. DC voltage (V)	600				
MPPT voltage range (V)	100-500				
Turn on voltage (V)	120				
Turn off voltage (V)	120				
Number of MPP trackers	2				
Max. DC current per MPPT (A)	11				
Number of MPPT's	2				
DC connections per MPPT	1				
Total number of strings	2				
DC connection type	MC4				
<b>Output</b>					
Nominal AC power (W)	3000	3600	4000	4600	5000
Max. AC power (W)	3300	4000	4400	5000	5000
Nominal AC current (A)	13.0	15.7	17.4	20.0	21.7
Max. AC current (A)	15.7	16.0	21.0	23.8	25.0
Power connection	Single phase				
Grid voltage range	According to VDE 0126-1-1, UL1741, G83/2, AS4777				
Grid frequency range	According to VDE 0126-1-1, UL1741, G83/2, AS4777				
Power factor	0.8 ... 1 ... 0.8				
Harm. distortion at nom. output	< 1.5%				
AC connector	Plug in connector				
Overvoltage category	OVC III (MAINS), OVC II (PV)				
<b>Power consumption</b>					
Night power consumption (W)	< 1				
Standby power consumption (W)	6				
<b>Efficiencies</b>					
Max. efficiency	98.1%				

Euro efficiency	97.3%
MPPT efficiency	>99.5%
	<b>S2.MX3000(S)-MII</b> <b>S2.MX3600(S)-MII</b> <b>S2.MX4000(S)-MII</b> <b>S2.MX4600(S)-MI I</b> <b>S2.MX5000(S)-MII</b>
<b>Safety protection</b>	
Internal overvoltage protection	Yes
DC Insulation monitoring	Yes
Earth fault protection	Yes
Grid monitoring	According to VDE 0126-1-1, UL1741, G83/2, AS4777
Earth fault current monitoring	According to VDE 0126-1-1, UL1741, G83/2, AS4777
DC current monitoring	According to VDE 0126-1-1, UL1741, G83/2, AS4777
Islanding protection	According to VDE 0126-1-1, UL1741, G83/2, AS4777
CE- compliant	According to EN 62109, EN 61000-6-1, EN 61000-6-3, EN 61000-6-2, EN 61000-6-4, EN61000-3-2, EN61000-3-3, EN61000-3-12, EN61000-3-11
<b>General data</b>	
Dimensions (W x H x D) (mm)	310 x 543 x 160
Weight	11.5kg
Installation environment	Indoor or outdoor
Mounting	Wall bracket
Operating temperature range (°C)	-25 to 60
Max. relative humidity	0 to 100%
Maximum altitude	4000m
IP protection rating	IP65 according to EN60529
Isolation type	Transformerless
Cooling concept	Convection
Noise level (dB)	< 30
LED indicators	3
LCD display	2 x16 characters
Communication interfaces	RS485
Optional interfaces	Wi-Fi 802.11, RS232, RJ45, GPRS
Standard warranty	5 years, extendable to 15 years
Integrated DC switch	Optional